



User s Manual

(Solar System)

Catalog


1. Product introduction:	1
1.1.Introduction to working principle.....	1
1.2. Introduction to working mode	1
2.Operation instruction	2
1.Opening packing inspection:	2
3.Installation notice:	3
4. Outward appearance and wiring	4
4.1. Outward	4
4.2wiring.....	5
5. Specification :.....	9
5.1.0001Appendix 1)	9
5.2.0002 (Appendix 2)	9
6. Indicators、 buttons and display description:	9
7.parameter setting:	11
8.Product care and maintenance	16
9. Fault code and repair	17
9.1. Fault codes and maintenance	17
9.2. buzzer alert	19
10. External communication.....	19
Appendix1.0001-0002.....	1
Appendix1.0002	3

1. Product introduction:

The inverter is suitable for mains power unstable or often off, and important equipment that requires backup power. This product adopts high-precision DSP control chip, precise detection circuit, advanced control technology, modular design is more convenient for installation and maintenance. Intelligent temperature-regulating fan, efficient heat dissipation, extending system life. The output is stable, clean and pure sine wave output. There are four working modes to choose: mains priority mode, battery priority mode, energy saving mode, and unattended mode. Has short circuit protection, overvoltage and under voltage protection, overload protection, Overheat / short circuit automatic restart (automatic restart three times), wide frequency and wide voltage input, can be used for diesel / gasoline generator input.

1.1. Introduction to working principle

AC220-240V:300W-6000W: with AVR
AC110-120V:300W-3000W: with AVR



1.2. Introduction to working mode

01 Mains priority

When the main power is available, the main power supply power to the load, and when the mains power is off, the battery will supply power to the load. You can set the mains power charge the battery or not (PC set).

02 Energy saving mode

When the inverter is in battery priority mode and the output load is less than 1%-10% of the power(set by the P7 ,10% default), the AC power output will be turn off, The inverter restarts every 1 minute, and checks whether the load is greater than the set power. When the connected load is greater than the minimum setting, the inverter restarts output. This function is to reduce the battery loss and extend the battery backup time.

03 Battery priority mode

The battery supply power to the load. When the battery voltage is lower than the set battery voltage(voltage set by PA item), use main power supply power to the load. When the battery voltage is restored , the battery will supply power to the load again (When battery power is low or solar power is off, the inverter can be set by PC ot use main power charging the battery or not) .

04 Mains priority unattended mode

Inverter automatically turn on when connected to mains power or battery voltage is normal (not include inverter first time use) . But when the battery discharge voltage lower than battery voltage by set F4 (F4: set the battery low voltage power is turn off), the power will be turned off. Inverter on only mains power is coming or turn on by hand.(mains is charging is or not set by PC)

05 Battery priority unattended mode

When the battery voltage is normal ,the inverter automatically turn on and battery supply power to the load. When the battery is low voltage ,mains power supply power to the load. When the battery discharge to battery low voltage shutdown (PL setting), the inverter enters standby and waits for the mains power or solar charging to battery .When the battery voltage is restored (PN setting),the inverter automatically turn on .But when the battery discharge voltage is lower than battery voltage (set by F4), power will be turn off .Inverter turn on only main power is coming or turn on by hand,

2.Operation instruction

1.Opening packing inspection:

Check the package is complete before opening. After opening packing please check the accessories, The accessories includes 1PCS user manual and check the inverter is still protected well after transportation.


note:

- ◆ Read the product manual carefully before using this product.
- ◆ If you find damage or missing parts, please do not turn on the machine and contact your dealer.
- ◆ Please keep the packing box and materials for can be for next delivery if need.

- ◆ This series of products is very heavy, please handle it carefully .

3.Installation notice:

1. The inverter must be more than 30cm away from the wall, well ventilated, free of water, flammable gases and corrosives. As shown in the figure:



2. Don't place any goods in a corner, side, or upside down, away from heat sources. To avoid direct sunlight, ensure that the front panel, rear panel, and fan inlets have good ventilation.
- 3.The environment temperature should be between 0 °C and 40 °C.
- 4.If the machine is disassembled and used in a low temperature environment, water condensation may occur. In order to avoid any shock risk, make sure to operate the machine in a dry environment both inside and outside.
- 5.Please install the inverter near the mains input socket or switch. It is easy to unplug the mains input or cut off the power supply in case of emergency situation..
- 6.The external battery should not be exposed. It should be installed in the battery cabinet..
- 7.The DC input between inverter should be short as possible
- 8.Do not stack goods on the inverter.





note:


- ◆ When the load is connected to the inverter, the load must be turned off before wiring, and then turned on the loads one by one.
- ◆ The inverter is connected to a socket with over current protection, and the machine is safely grounded.
- ◆ The power outlet should be safely grounded.
- ◆ Whether the inverter has input or not, the inverter may have output, turning off the inverter does not ensure that the internal parts are not have power. If need to make the inverter no output, must turn off all switches first, then turn off the mains power supply.
- **Need to touch inductive load: Before using inductive load such as motor, display, laser printer. Make sure that the inverter capacity is three times higher than load equipment power .**

4. Outward appearance and wiring

4.1. Outward

0001:






200AH System


4.2wiring

1. Battery wiring example:

1.1. 12V:300W-1200W connection diagram:




1.2. 24V:1000W-6000W connection diagram:




2.wiring examples:

2.1. 12V:300W-500W connection diagram:




2.2. 24V:1000W-6000W connection diagram:




3. Solar panel and battery connection instructions:

3.1. Solar panels or batteries in series:




Solar panel voltage = 1 + 2 + 3 + ... n, the voltages of each solar panel are added together.




Battery voltage = 1 + 2 + 3 + ... n, the voltages of each battery are added together.

3.2. Solar panel or battery in parallel:



Solar panel voltage = 1 = 2 = 3 = ... n, the voltage of 1PCS solar panel (the voltage of each panel must be the same to be connected in parallel).



Battery voltage = 1 = 2 = 3 = ... n, the voltage of 1PCS battery (the voltage of each battery must be the same to be connected in parallel).

note:

*If you want to connect the inverter to diesel generator or gasoline generator, please follow these steps:


1. Turn on the generator, after it works stably, connect generator output to the inverter input (Confirm the inverter is no-load), then turn on the inverter as normal. After the inverter starts working, connect the load.
2. Recommended generator capacity is 2-3 times larger than the inverter.

5. Specification :

5.1.0001 Appendix 1)

5.2.0002 (Appendix 2)

6. Indicators、 buttons and display description:



1. Indicator:

Green light :

In the mains working mode, the LED light is on when the mains is working, the green light off when the inverter is inverting.

Yellow light:


Inverter working mode indicator and mains charging indicator. When the inverter is working it always lighting and the mains charging for battery it flashes. It will off when charging is completed. In the 03 battery priority mode, the PC menu determines the light is on or off during charging.

Red indicator:

Lights flashing when the overload is more than 105%, lighting when the overload is more than 110%, lighting when the inverter fails, lights flashing when the battery is low.

2. When the inverter is off, press(ON / OFF) button and hold 3 seconds to turn on the inverter and buzzer will sound. When inverter is on press(ON / OFF) button and hold 3 seconds to turn off the inverter

3. When the inverter works, you can press UP or DOWN to check display parameters:




Inverter mode



Mains mode (battery capacity icon flashing when charging, when no charging or complete it will stop flashing)



Battery priority mode, mains status (mains icon will flash)




Frequency display




Load % display




Load power display




Overload display (when icon will flashes)



Battery % display




Battery voltage display



Inverter total output power display




Solar input with mains



Solar input without mains



Solar input voltage display



Solar input current display

7.parameter setting:

1. When the inverter in the normal working , press the **SET** button for 5S to enter the setting menu. Enter the setting menu, LCD shows the working mode icon is flashing. At this time, press the **UP** button or the **DOWN** button to operate the menu options. The working mode icon will change depending on the operation. When in the right menu option, press the setting button **SET** 3S to enter the setting parameters,(At this

time, the working mode icon is not flashing, in the left parameter item is flashing.) Press the up or down button to select the setting parameter, press the SET button 3S to exit the setting.(At this time, the working mode icon flashes, and the parameter icon does not flash.) To exit the mode (**ESC**), press the **SET** button 3S to enter the set parameters and then press the **SET** button 3S to exit the setting menu and save the settings, You need to press the shutdown key to set the parameters to save normally.




P0:Set work mode menu:

Press the SET button 3S to enter the setting menu, the menu selection icon is flashing. If need save and exit, press the SET button 3S to save and exit



P1: work mode setting:

- 01: Mains priority mode
- 02: Energy saving mode
- 03: Battery priority mode
- 04: Mains priority Unattended mode
- 05: Battery priority Unattended mode



P2: Battery type and charging voltage setting:


SLD: lead-acid battery (default), GEL: gel battery, LI: lithium battery, USE: user mode. Select USE user mode to adjust battery voltage in P3 and P4 menus. If you do not select the USE user mode, the P3 and P4 menus will not appear.



P3: Battery voltage uniform charge setting:
12.5V ~ 15.5V (single) can be set



P4: Battery voltage floating charge setting:
12.5 ~ 13.9 (single) can be set



P5: Maximum mains charging current setting:
(Default
300W:5A,500W-600W:10A,700W-1500W:20A、2000W:20A,3000W-12000W:50A) 5A, 10A, 20A, 30A, 40A, 50A.



P6: Buzzer sound setting:
ON: Turn on the buzzer, OFF: Turn off the buzzer (overvoltage, under voltage, overload, over temperature, except faults)



P7: Energy saving mode AC output setting:
(10% default), in (USE) user mode, can be adjusted up and down 1.0-10% / 1%



P8: Inverter output voltage setting:
220V default, (208V, 210V, 220V, 230V, 240V)

110V default, (104V, 105V, 110V, 115V, 120V)



P9: AC Output frequency setting:
50Hz default, (50Hz, 60Hz)



PA: battery priority mode battery under voltage to mains voltage setting:
10.5V default, (single section: 10.5V, 10.6V, 10.7V, 10.8V, 10.9V, 11.0V, 11.1V, 11.2V, 11.3V, 11.5V)



PB: battery priority mode, when battery voltage is restored inverter from city power conversion inverter voltage:
13.2V default, (single battery: 13.2V, 13.3V, 13.4V, 13.5V, 13.7V, 13.9V, 14.1V, 14.4V)



PC: battery priority mode, mains is charged or not:
AUOT default, ON (battery priority with AC charging), OFF (battery priority without AC charging), Automatic detection solar priority or city power priority, select solar charging, the mains will charge when the solar charging current is small) The specific charging method is as follows:

The relationship between solar charging and mains charging:	
Solar charging current	Mains charging current (* maximum set charging current)
40A	0%
30A	20%
20A	40%
10A	60%
5A	80%
0	100%




Pd: AC input lowest voltage setting:
 AC220V:Default 160VAC, (140V, 150V, 160V, 170V, 180V)
 AC110V:Default 80VAC, (70V, 75V, 80V, 85V, 90V)



PE: AC input highest voltage setting:
 AC220V:Default 275V, (260V, 265V, 270V, 275V, 280V, 285V, 290V)
 AC110V:Default 137V, (130V, 132V, 135V, 137V, 140V, 142V, 145V)



PF: AC input minimum frequency setting:
 Default 45Hz, (40Hz, 41Hz, 42Hz, 43Hz, 44Hz, 45Hz)



PH: AC input maximum frequency setting:
 Default 63Hz, (63Hz, 64Hz, 65Hz)



PL: Battery low voltage shutdown setting:
 (must : $P_n > P_L > F_4$)
 10.2V default, 9.5V ~ 12.0V (single) can be set



Pn: unattended mode, battery under voltage restores the startup voltage setting:(must : $P_n > P_L > F_4$)
 12.4V default, 11.0V ~ 13.0V (single) can be set



F3: Generator mode setting:
Default OFF (ON \ OFF)



F4: Unattended mode battery voltage low power off power point setting: **(must : Pn>PL>F4)**
Default single section 10.0V (9.0V-12.0V can be set)



F5: Fan failure detection settings:
Default single block OFF (ON, OFF)



F9: Negative temperature detection setting:
The default OFF, (ON, OFF) When the temperature is below -15 °C use the machine, please turn on this setting (ON)

8.Product care and maintenance

8.1. This series of inverters just need less maintenance. The standard battery type is valve-regulated lead-acid battery, Need to keep charging often to extend battery life. When the inverter is connected to the mains, whether it is on or off, it still keep charging the battery, and provides overcharge and over discharge protection.

8.2. If the inverter is not used for a long time, need to charge it every four to six months. Charge the battery for 4-6 hours before use.

8.3. Normally , the battery life is three to five years. If there is a problem with the battery, it must be replaced early. When replacing the battery, it must be operated by professionals.

8.4. It is not recommended to replace the battery individually. When replacing, should follow the battery supplier's operating instructions.

8.5. Normally, the battery is charged and discharged every four to six months, and start charged after discharging off, the charging time of the standard machines should not be less than 12 hours.

8.6. In high temperature areas, the battery is charged and discharged every two months, the standard machine charge should not be less than 12 hours.

note:

*Before replacing the battery, you must cut off all power connected to the machine: mains switch, battery switch, etc.

*Take off metal objects such as rings and watches.


*Use tool as handles and screwdrivers. Do not put tools or other metal objects on the battery.

* It is normal for a small spark when connecting the battery cable, but will not harm human safety and inverter.

Note: Do not short the battery positive and negative, can't connection reverse battery.

9. Fault code and repair

◆ This icon  will flash when there is a fault.



9.1. Fault codes and maintenance

Cause of fault	Buzzer or indicator	Fault cause	Solution
E01		Battery low voltage	Check the battery is broken or not
E02	1 long 2 short B-BB shout, red light is off	Battery overvoltage	Check the battery is broken or not
E03	Buzzer urgent shouting,	Battery low voltage	Check the battery is

	the red light lighting		broken or not
E04	Intermittent ringing, red light is off	Transformer secondary line reverse connection	Restart or contact the supplier
E05	Keep shouting, red light keep lighting	Inverter startup failure	Check output have short circuit、overload or not
E06	Keep shouting, red light keep lighting	Output for short circuit	Check output have short circuit、overload or no
E07	Keep shouting, red light keep lighting	Output voltage is too low or overloaded	Check output voltage and load
E08	Keep shouting, red light keep lighting	Temperature is too high	Check the fan is working
E09	Output Low voltage		
E10			
E11	Keep shouting, red light keep lighting	Low temperature or temperature control failure	Check the temperature control lines are not open circuit , dropped
E12			
E13			
E14	Keep shouting, red light off	Fan open circuit	Check the fan are not open circuit , dropped
E15		Input relay short circuit	Tap the input relay to check it broken or not
ES0	Displayed when press the controller display page	Controller work well	Controller work well
ES3	Displayed when press the controller display page	Controller over current	Internal fault
ES4	Displayed when press the controller display page	Controller temperature high	Internal fault
ES5	Displayed when press the controller display page	Solar input overvoltage	Check Solar input voltage and correct number of solar panels
ES6	Displayed when press the controller display page	Solar input low voltage	Check Solar input voltage and solar panels not have damaged

9.2. buzzer alert

Buzzer sound:

- 1) Inverter: A beep sounds every 10 seconds. 10S --- 10S ---
- 2) When the battery voltage is low, one sound per second. --1S--1S--
- 3) When the battery is high voltage: three sound every four seconds, one long and two short. 4S -----
- 4) Overload:
 - > 110% long sound. ----
 - > 105% sound every two seconds. 2S --- 2S ---
- 5) Temperature control failure: 2 sound every 4 seconds 4S-- --4S---
- 6) The temperature is too high: sound every two seconds. 2 --- 2 ---
- 7) Fan abnormality: long sound ---

10. External communication

Support RS232,RS485, USB, SNMP communication

Appendix1.0001-0002

Mode		300W	500W	600W	700W	1000W	1200W
Rated power		300W	500W	600W	700W	1000W	1200W
Input	voltage	AC 110V: 73-138VAC ,115V: 78-143VAC,120V:83-148VAC,AC 220V:145-275VAC,230V:155-285VAC,240V:165VAC-295VAC					
	Frequency	45-65Hz(Mains mode)			50/60Hz±1%(Battery Mode)		
Output	Voltage	AC 110/120/220/230/240V ±15%(Mains mode)			AC 110/120/220/230/240V ±2%(Battery Mode)		
Output waveform		Pure sine wave					
Efficiency		>85%					
Type of battery		Optional					
Battery rated voltage		12V					
AC charging current (MAX)		300W:5A,500W-600W:10A (MAX) can be set 5-10A			700W-1200W20A (MAX) can be set 5-10-20A		
Protection		Overload, short circuit, battery high and low voltage, AC input high and low voltage protection					
Conversion method		Interactive					
Overload capacity		Overload 110-120%, the output will turned off after 30S.Overload 160%, the output will turned off after 30ms.					
Solar charger controller	Type	PWM solar charger controller			MPPT solar charger controller		
	Current	10A~30A			20A~30A		
	PV input (max)	12V:22V (MAX)			12V/24:80V(MAX)		
	Input power(max)	12V:10A:120W/20A:240W/30A:360W(MAX)			12V:20A:240W/30A:360W(MAX)		
Communication port		RS232/RS485/USB/SNMP(Optional)					
working environment	temperature	-15℃~+50℃					
	Humidity	10%~90%					

Mode		500VA	700VA	800VA	1000VA	1200VA	1500VA
Rated power		500VA	700VA	800VA	1000VA	1200VA	1500VA
Input	voltage	AC 110V: 73-138VAC ,115V: 78-143VAC,120V:83-148VAC,AC 220V:145-275VAC,230V:155-285VAC,240V:165VAC-295VAC					
	Frequency	45-65Hz(Mains mode)			50/60Hz±1%(Battery Mode)		
Output	Voltage	AC 110/120/220/230/240V ±15%(Mains mode)			AC 110/120/220/230/240V ±2%(Battery Mode)		
Output waveform		Pure sine wave					
Efficiency		>85%					
Type of battery		Optional					
Battery rated voltage		12V					
AC charging current (MAX)		500VA:5A,700VA-800VA:10A (MAX) can be set 5-10A			1000VA-1500VA:20A (MAX) can be set 5-10-20A		
Protection		Overload, short circuit, battery high and low voltage, AC input high and low voltage protection					
Conversion method		Interactive					
Overload capacity		Overload 110-120%, the output will turned off after 30S.Overload 160%, the output will turned off after 30ms.					
Solar charger controller	Type	PWM solar charger controller			MPPT solar charger controller		
	Current	10A~30A			20A~30A		
	PV input (max)	12V:22V (MAX)			12V/24:80V(MAX)		
	Input power(max)	12V:10A:120W/20A:240W/30A:360W(MAX)			12V:20A:240W/30A:360W(MAX)		
Communication port		RS232/RS485/USB/SNMP(Optional)					
working environment	temperature	-15℃~+50℃					
	Humidity	10%~90%					

Appendix1.0002

Mode		1000W	1500W	2000W	3000W	4000W	5000W	6000W
Rated power		1000W	1500W	2000W	3000W	4000W	5000W	6000W
Input	voltage	AC 110V: 85-138VAC ,115V: 90-143VAC,120V:95-148VAC,AC 220V:170-275VAC,230V:180-285VAC,240V:190VAC-295VAC						
	Frequency	45-63Hz(Mains mode)			50/60Hz±1%(Battery mode)			
Output	Voltage	AC 110/120/220/230/240V ±2%(Battery mode)		AC 110/120/220/230/240V ±15%(Mains mode)		AC 170-275V(Mains mode)		
		Pure sine wave						
Output waveform		Pure sine wave						
Efficiency		>85%						
Type of battery		Optional						
Battery rated voltage		12/24VDC			24VDC			
AC charging current (MAX)		30A(MAX)can be set 5-10-20-30A		50A (MAX) can be set 5-10-20-30-40-50A				
Protection		Overload, short circuit, battery high and low voltage, AC input high and low voltage protection						
Conversion method		Interactive						
Overload capacity		Overload 110-120%, the output will turned off after 30S.Overload 160%, the output will turned off after 30ms.						
Solar charger controller	Type	PWM solar controller			MPPT solar controller			
	Current	10A~60A			10A~80A			
	PV input (max)	12V:22V/24:45V/48:75V/96V:145V(MAX)			12V/24V:20A-30A:80V,12V/24V:40A-80A:130V(MAX)			
	Input power(max)	12V:10A:120W/20A:240W/30A:360W/50A:600W/60A:720W/80A:960W (MAX) 24V:10A:240W/20A:480W/30A:720W/50A:1200W/60A:1440W/80A:1920W (MAX)						
Communication port		RS232/RS485/USB/SNMP(Optional)						
working environment	temperature	-15℃~+50℃						
	Humidity	10%~90%						

Mode	1200VA	2000VA	3000VA	5000VA	6000VA	7000VA	8000VA
Rated power	1200VA	2000VA	3000VA	5000VA	6000VA	7000VA	8000VA
Input	voltage	AC 110V: 85-138VAC ,115V: 90-143VAC,120V:95-148VAC,AC 220V:170-275VAC,230V:180-285VAC,240V:190VAC-295VAC					
	Frequency	45-63Hz(Mains mode)			50/60Hz±1%(Battery mode)		
Output	Voltage	AC 110/120/220/230/240V ±2%(Battery mode)		AC 110/120/220/230/240V ±15%(Mains mode)		AC 170-275V(Mains mode)	
		Output waveform					
Efficiency		>85%					
Type of battery		Optional					
Battery rated voltage		12/24VDC			24VDC		
AC charging current (MAX)		30A(MAX)can be set 5-10-20-30A		50A (MAX) can be set 5-10-20-30-40-50A			
Protection		Overload, short circuit, battery high and low voltage, AC input high and low voltage protection					
Conversion method		Interactive					
Overload capacity		Overload 110-120%, the output will turned off after 30S.Overload 160%, the output will turned off after 30ms.					
Solar charger controller	Type	PWM solar controller			MPPT solar controller		
	Current	10A~60A			10A~80A		
	PV input (max)	12V:22V/24:45V/48:75V/96V:145V(MAX)			12V/24V:20A-30A:80V,12V/24V:40A-80A:130V(MAX)		
	Input power(max)	12V:10A:120W/20A:240W/30A:360W/50A:600W/60A:720W/80A:960W (MAX)					
24V:10A:240W/20A:480W/30A:720W/50A:1200W/60A:1440W/80A:1920W (MAX)							
Communication port		RS232/RS485/USB/SNMP(Optional)					
working environment	temperature	-15℃ ~+50℃					
	Humidity	10% ~90%					